



# Locking systems with space between holes 95/105/130



## 1. Lock type RS - space 95/105/130mm

### SPACE BETWEEN 95\*:

RS400, RS400U	1B-6
RS500, RS500U	1B-6
RS520, RS520U, RS420, RS420U	1B-6

### SPACE BETWEEN 105:

RS100, RS100U, RS100T	1B-3
RS200, RS200U, RS200T	1B-3
RS110, RS210, RS800	1B-4

### SPACE BETWEEN 130:

RS130, RS140	1B-9
--------------	------

2. Swinghandle RS510 - space 95mm	1B-8
3. Profile cylinder	1C-1-3
4. Nut M22x1,5	-
5. 1-point cam without limiter	1C-12
6. 2-points, 3-points cam without limiter	1C-15, 19
7. Rod Ø6	1C-4
8. Rod guide Ø6	1C-6
9. Rod Ø8	1C-5
10A. Rod guide Ø8   10B. Rod guide RW	1C-6-7
11. Door of the box	-
12. Edge of the box	-