


System zamykania wg rozstawu 95/105/130



1. Zamek RS - roz. otworów 95/105/130mm

ROZSTAW 95*:

RS400, RS400U	1B-6
RS500, RS500U	1B-6
RS520, RS520U, RS420, RS420U	1B-6

ROZSTAW 105:

RS100, RS100U, RS100T	1B-3
RS200, RS200U, RS200T	1B-3
RS110, RS210, RS800	1B-4

ROZSTAW 130:

RS130, RS140	1B-9
--------------	------

2. Zamek RS510 - rozstaw otworów 95mm	1B-8
3. Wkładka	1C-1-3
4. Nakrętka M22x1,5	-
5. Język 1-pkt bez ogranicznika	1C-12
6. Język 2-pkt, 3-pkt bez ogranicznika	1C-15, 19
7. Pręt Ø6	1C-4
8. Prowadnica metalowa Ø6	1C-6
9. Pręt Ø8	1C-5
10A. Prowadnica Ø8 10B. Prowadnica RW	1C-6-7
11. Drzwi szafy	-
12. Rant szafy	-