

Lock M22SP

RST Roztocze
LOCKING SOLUTIONS



Lock with backlash compensation and protection in case of accidental opening. In order to open/close the lock first press the insert and then turn  $90^\circ$  degrees.



<sup>\*</sup> possibility to make in another dimension

The lock is fitted with cams from the group: 12, 14, 17, 17A, 18, 32, 34, JK1-16018, JK2-16018, J-6000.03, J-6000.04, JK-1610.01, JZ-002 (pg. 1C-10 to 1C-23)